

# ark Auto Permanent Mount Key Safe Installation Guide



## Installing on brick, concrete or stone walls

To mount the ark Auto Permanent Mount key safe on a wall, the following tools are needed:

- 5mm or 3/16" masonry drill bit (capable of drilling 70mm/2.75 inches deep)
- Drill
- Marker pen or pencil
- T30 Torx screwdriver
- Spirit level
- Safety goggles (recommendation)
- Dustpan
- Brush
- 4x Standard Security Screws (included)

**Hold the key safe up to the wall where you would like to install it, ensure that the key safe doesn't move or rock. Ensure it sits flat against the wall to warping.**

**If installing on brick, try to ensure the holes line up with the horizontal centre of the surface of each brick, and not in the mortar line.**



1. Open the lid and use a marker pen/pencil to mark the positions of the mounting holes on a wall.
2. Mark up the drill to 70mm in length. Put on eye protection.
3. Drill four holes to a depth of at least 70mm. Failure to drill deep enough can result in a snapped screw.
4. Clean out the dust and debris from the holes by blowing gently into them.
5. Place the ark Auto key safe over the holes.
6. Use the four Standard Security Screws (included).
7. Drive the screws directly into the brick using a T30 Torx screwdriver. **Do not use power tools.** Using power tools might cause damage to the screws and the surface.
8. Tighten the screws until the heads are snug against the back of the key safe. **Do not over-tighten the screws.**

## Installing on wooden structures and substrates

To mount the ark Auto to a wooden surface or substrate, the following tools are needed:

- 4mm or 5/32" drill bit (capable of drilling 70mm/2.75 inches deep)
- Drill
- Marker pen or pencil
- T30 Torx screwdriver
- Spirit level
- Safety goggles (recommendation)
- Dustpan
- Brush
- 4x Standard Security Screws (included)

**Ensure that the installation substrate is at least 25mm (1 inch) thick, ideally 60mm (2.5 inches) or more.**

**If installing on thin walls be aware the screws may protrude through the back side.**

**Install the key lock box where possible into a stud. Hold the key lock box against the surface where you plan to install it.**

1. Open the lid and use a marker pen/pencil to mark the positions of the mounting holes on a wall.
2. Mark up the drill to 70mm in length. Put on eye protection.
3. Drill four holes to a depth of at least 70mm. Failure to drill deep enough can result in a snapped screw.
4. Clean out the dust and debris from the holes by blowing gently into them.
5. Place the ark Auto key safe over the holes.
6. Use the four Standard Security Screws (included).
7. Drive the screws directly into the wood using a T30 Torx screwdriver. **Do not use power tools.** Using power tools might cause damage to the screws and the surface.
8. Tighten the screws until the heads are snug against the back of the key safe. **Do not over-tighten the screws.**

**If you wish to install the product on a different surface than a wall, please use screws suitable for that material.**